

Phone Outlet Charging Holder

1. Draft pattern.
2. Cut one face and one contrast.
3. Put right sides together and stitch the sides and bottom with a $\frac{1}{2}$ " seam allowance, leaving top open to turn.
4. Clip bottom corners.
5. Turn right side out.
6. Insert a 5" by 9 $\frac{1}{2}$ " piece of Skirtex™ inside at the top, stopping it at the fold line.
7. Fold in top $\frac{1}{2}$ " and top stitch closed.
8. Fold bottom edge up 5" (where Skirtex™ ends), and meet tapered edges to side edges.
9. Stitch through all four layers of side close to the seamed edges.
10. Separate front and back of snap together grommet.
11. Using the back side of the grommet as a template, enter grommet on top section of holder and trace inner circle.
12. Cut out circle.
13. Insert grommet and snap together.

